

## Preparation for Cutwork Embroidery Designs by using the Artistic Digitizer Jr.

The Cutwork Embroidery Designs can be used on the CM17, which has a Ready to Sew Window dedicated to Cutwork patterns.

This manual explains how to edit and send the Cutwork Designs to the CM17 by using the Artistic Digitizer Jr..

(CUT\_4\_01 and CUT\_1\_04 are chosen as an example)

\*Cutwork Designs (zipped) need to be downloaded from the web page.




1. Download the zip file "Cutwork\_Designs\_Draw" and save it on your PC or Mac.


\*Please refer to the instructions "How to Unpack a Zip File".

2. Start the Artistic Digitizer Jr. Software.




\*Artistic Digitizer version 1.7 or later is required.




3. Click "Create new".





4. Click "Open" and select "CUT\_4\_01", then click "OK".




5. Click "To MC15000" and select "Change..." on the pop-up menu.




6. Select "CM17" and "RE20d".



7. Drag “CUT\_1\_04” from “Cutwork\_Designs\_Draw” folder to the editing screen.




8. Print the template sheet as needed.  
Click “Print”.






a. Click "Design Only".




b. Select the check boxes "Center lines", "Hoop" and "Grid Line".  
Then, print the template sheet. ("Fill areas" is checked by default)




9. To send the design to "Ready to Sew" of the CM17, select "Cable Connection" or "By WLAN (wireless LAN)".


\*Set up the CM17 for embroidery before sending the designs.



Select "Ready to Sew" and click "Send".



10. Ready to start Embroidering Cutwork Designs with the CM17.



\*For detailed instructions on how to embroider Cutwork Designs with the CM17, please refer to "Cutwork Manuals".